



INSTALLATION

- 1 Ensure that the head of the Pemflex Door is level with the top of your door opening.
- 2 After hanging, allow 15 mm clearance between the strip and the floor. If necessary trim each strip individually with scissors to the correct length.

IMPORTANT - FOR SAFETY REASONS UNDER NO CIRCUMSTANCES HAVE THE STRIPS TOUCHING THE FLOOR.

CLEANING

- 1 We recommend washing the Pemflex Door in hot water only.
- 2 DO NOT USE SOAP OR DETERGENTS.
- 3 YOU MAY USE LIQUID WINDOW CLEANER.